

STUDIO•M

SM251310

Please consult your electrician for hanging fixture and wiring.

It is recommended that this fixture be installed by a licensed electrician.

1. Turn off breaker at electrical panel
2. Assemble metal shade J to framework C using flathead screw A and ball-nut H.
3. Install mounting bar to outletbox.
4. Adjust cables to proper height.
5. Install fixture to outlet using nipple and cap nut provided.
6. Install crystal strands B to rows D, E, and F.
7. Install 40 watt Xenon bulbs into sockets.

Warning!!! Xenon lamps burn extremely hot. Turn fixture off and allow bulbs to cool at least 15 minutes before touching.

