


STUDIO•M

SM564361

Please consult your electrician for hanging fixture and wiring.

PRODUCT NAME: Civic Outdoor Lantern
ITEM NUMBERS: 54361 / 54363 / 54365

Please consult your electrician for hanging fixture and wiring.



WARNING:

Fixture may be dimmed using an electronic low voltage dimmer.


Bulb (included): 6W / 11W / 11W LED

STUDIO•M


SM564361

Please consult your electrician for hanging fixture and wiring.


IMPORTANT: Turn off the power at the main fuse or circuit breaker box before starting installation



Locate all hardware & components before discarding packaging




1.)



Step 1: Remove mounting bracket from fixture and install it to the electrical box. Wire fixture to wires in outlet box. Green wire is for ground

2.)



Step 2: Put the rubber washer (E) on the glass and then lock until tight.

Note: the rubber washer (E) is packet with the canopy kit

Cleaning & Care:

Clean with soft cloth and a mild detergent Do not use abrasive cleaner.