


STUDIO•M

SM264722

Please consult your electrician for hanging fixture and wiring.

Please consult your electrician for hanging fixture and wiring.



Bulb(not included) E12 2 x MAX 40W


STUDIO•M

SM264722


Please consult your electrician for hanging fixture and wiring.

IMPORTANT: Turn off the power at the main fuse of circuit breaker box before starting installation

- (A)  Ball Nut(2PCS) (B)  Mounting Bracket (C)  Mounting Screws(2pcs)
- Locate all hardware & components before discarding packaging




1.)



step1: Remove mounting bracket (B) from fixture and install to electrical box using mounting screws (C).

2.)



step2: Wire fixture to wires in outlet box. Copper wire is for Ground. Attach wall sconce to mounting bracket and tighten ball nuts (A) so fixture meets wall.

Cleaning & Care:

Clean with soft cloth and a mild detergent.
Do not use abrasive cleaner.

MADE IN CHINA

Page 2 of (3)


STUDIO•M


SM264722

Please consult your electrician for hanging fixture and wiring.


IMPORTANT: Turn off the power at the main fuse of circuit breaker box before starting installation

(D) 
Lock Screws(4pcs)


(E) 
Bulb(Not Included)

(F) 
Glass Shade

Locate all hardware & components before discarding packaging



3.)



step3: Loosen the lock screws (D). Install E12 bulb(E) and attach glass (F). Secure glass (F) by tightening lock screws (D).

Cleaning & Care:

Clean with soft cloth and a mild detergent.
Do not use abrasive cleaner.

MADE IN CHINA

Page 3 of (3)