



STUDIO•M

SM369746

Please consult your electrician for hanging fixture and wiring.



NO.	Color	MAXIM#	Q'ty	Length	Component
A	Red	ARM39745PC-A	1	13.7-13.9"	Spoke ball
B	Chrome	ARM39745PC-B	6	10.8-11.1"	Beveled crystal
C	Red	ARM39746PC	30	14.5-14.7"	Spoke ball
D	Chrome	ARM39746PC	18	14.2-14.4"	Beveled crystal




STUDIO•M


SM369746

Please consult your electrician for hanging fixture and wiring.


A-Red stem:ARM39746PC 30pcs L14.5-14.7"





B-Chrome stem:ARM39746PC 18pcs L14.2-14.4"



C-Red stem:ARM39745PC-A 1pc L13.7-13.9"



D-Chrome stem:ARM39745PC-B 6pcs L10.8-11.1"



NO.	MAXIM#	Q'ty	Size
A	CJE39740-A	48	D0.5"
B	CJE39740-B	372	D0.55"
C	CJE39740-C	217	D0.7"
D	CJE39740-D	155	D0.8"
E	CRB39740	24	D2.35"*H1.2"

STUDIO•M

SM369746

Please consult your electrician for hanging fixture and wiring.

1. Turn breaker off for circuit on outlet where fixture is to be installed.
2. Remove mounting bracket from fixture and install to electrical box
3. Wire fixture using green wire as ground.
4. Install fixture to mounting bracket and secure by tightening ball nuts.
5. Before install spoke balls onto end of red stems and secure with cap stem, make sure stems were tighten up.
6. Install beveled crystal onto end of chrome stems and secure with cap stem.
7. Install maximum 40 watt Xenon lamps included.

WARNING!

Xenon lamps burn hot. Allow 15 minutes after turning off before touching!

