
## STUDIO • M


SM369623


Please consult your electrician for hanging fixture and wiring.

IMPORTANT: Turn off the power at the main fuse or circuit breaker box before starting installation




Locate all hardware & components before discarding packaging






Step.1: Remove backplate (A) from fixture (B) and install to electrical box. Mark where anchors meet the wall. Drill holes using 3/16" ± drill bit where marked. Install backplate (A) to outlet box and attach anchors to secure bracket at ends.

Fixture



Step.2: Wire fixture to wires in outlet box. Copper wire is for Ground. Attach fixture (B) to the backplate (A) using screws (D) provided.



Step.3: Attach glass (C) to fixture (B) using screws (E).

## Cleaning & Care:

Clean with soft cloth and a mild detergent. Do not use abrasive cleaner.

Please consult your electrician for hanging fixture and wiring.

