
STUDIO • M

Please consult your electrician for hanging fixture and wiring.



The fixture is designed to dim with a standard Triac forward phase dimmer. Dimming levels will vary by dimmer.

Below is a list of recommended dimmers:

Lutron MACL-153M

Lutron DVL-153P

Lutron SCL-153P

Leviton IPL06-10Z

Leviton 6674-POW


Due to inrush current wattage should not exceed 150 watts of product for a 600 watt dimmer. WARNING: Wires need to be connected to driver found in canopy and should not be connected directly to power source or a short may occur.


WARNING: Wires need to be connected to driver found in canopy and should not be connected directly to power source or a short may occur.


To prevent water intrusion, caulk around back-plate where fixture meets the wall using outdoor silicone sealant. Leave a small gap at the bottom to allow moisture to exit.


LED 10.8W

IMPORTANT: Turn off the power at the main fuse or circuit breaker box before starting installation












Locate all hardware & components before discarding packaging







Step.1: Install Mounting bracket(A) to outlet box.



Step.2: Wire fixture to wires in outlet box. Green/Copper wire is for Ground.



Step.3: Install Backplate(B) to Mounting bracket(A).



Step.4: Caulk around fixture with outdoor silicone sealant to prevent water intrusion. Leave a small gap at the bottom to allow moisture to escape. Install fixture to backplate (B) and tighten mounting screws (D) to secure.

Cleaning & Care:

Clean with soft cloth and a mild detergent. Do not use abrasive cleaner.